

Indoor Alarmed Wall Cabinet

User Instructions



Indoor Alarmed Wall Cabinet

Repositioning the Door handle



1

During transit the door handle is secured inside the cabinet. The customer needs to unscrew the handle and reposition it on the outside of the cabinet.

Indoor Alarmed Wall Cabinet

Removing Battery Isolator Tab




2

During transit the batteries are isolated by a plastic tab
Pull the plastic tab out – and the alarm will be 'live'

Indoor Alarmed Wall Cabinet

Changing the Batteries



3 If you need to change the batteries – unscrew the screw holding the battery tray in place.

Beware! – Support the battery tray from below or once the screw is released – it could fall!

Indoor Alarmed Wall Cabinet

Changing the Batteries (cont)



4

Replace the batteries and secure the battery tray with the screw